


GENERAL NOTES

1. SAWCUT A CIRCULAR EXCAVATION AROUND MANHOLE OR VALVE  
(MANHOLE: 12" MIN. FROM FRAME  
VALVE: 6" MIN. FROM FRAME)
2. CONCRETE BACKFILL SHALL BE EARLY STRENGTH PORTLAND CEMENT CONCRETE.  
PROTECT FROM TRAFFIC LOADING UNTIL CONCRETE HAS CURED TO 3600 PSI.
3. APPLY TACK COAT TO EDGES AND CONCRETE SURFACE BEFORE PLACING HOT MIXED ASPHALT (HMA).
4. FINISH JOINT WITH ASPHALT SEAL AND SAND.



40-1

		<b>SANTA CLARA COUNTY ROADS AND AIRPORTS DEPARTMENT</b>				<b>STANDARD DETAILS</b> <b>MANHOLE &amp; VALVE ADJUSTMENT</b>		DRAWING NO. <b>C</b> <b>9A</b>					
NO.	REVISIONS	BY	DATE	APP'D	DESIGNED NC 6/17/14 DATE	CHECKED RC 6/30/14 DATE	WORK ORDER LEVEL BOOK TRANSIT BOOK	SUBMITTED: ROY W. B. CABALTERA SENIOR CIVIL ENGINEER <i>Roy W. B. Cabaltera</i>	APPROVAL: DAN COLLEN DEPUTY DIRECTOR <i>Dan Collen</i>			PROJECT NO. CONTRACT NO. FILE NO.	SHT. NO. <b>1</b> OF <b>1</b>